

PHONE GUIDE

CALLING FEATURES & DIALING RULES

| Code | Description | Instructions |
|------|-------------------------------------|---|
| *98 | Voicemail | See below for supported features |
| *43 | Call Waiting Enable | Enables Call Waiting for all future calls |
| *44 | Call Waiting Disable | Disables Call Waiting for all future calls |
| *48 | Anonymous Call Reject Enable | Reject all calls from anonymous numbers |
| *49 | Anonymous Call Reject Disable | All calls from anonymous numbers |
| *59 | Specific Caller Allow | Remove a phone number from your blocked-caller list |
| *60 | Specific Caller Block | Block calls from a specific phone number |
| *63 | Specific Caller Forward Enable | Forward all calls from a specific phone number |
| *65 | Enable User Caller ID Next Call | If Caller ID is disabled, use this to turn on Caller ID on the next call made |
| *67 | Block User Caller ID Next Call | If Caller ID is enabled, use this to turn off Caller ID on the next call made |
| *69 | Call Return | Calls the last inbound caller |
| *70 | Disable User Call Waiting Next Call | Turns off Call Waiting during the next call made |
| *72 | Call Forwarding | Will forward all future calls to the desired number |
| *78 | Do Not Disturb Enable | Sends all incoming calls to the unanswered failover (voicemail, forward to another number, busy signal) |
| *79 | Do Not Disturb Disable | Turns off Do Not Disturb |
| *99 | Call Forwarding — No Answer | Will forward calls to desired number when call unanswered |

VOICEMAIL GUIDE

Access Your Voicemail

- 1. Dial *98 from phone that's connected to your account.
- 2. Enter four-digit PIN followed by the pound (#) sign.
 - Default PIN is 1234. You will be prompted to change PIN for security purposes upon first use.
- 3. To listen to messages, press 1.

| motor to moodages, proce m | | | | |
|----------------------------|----------------|---------|--|--|
| • | Skip message | Press 1 | | |
| • | Save message | Press 2 | | |
| • | Erase message | Press 3 | | |
| • | Repeat message | Press 9 | | |
| • | Exit the menu | Press 0 | | |

Remote Access to Voicemail

- 1. Dial your 10-digit phone number.
- 2. When you hear your voicemail greeting, press the pound (#) sign.
- 3. Enter your four-digit PIN followed by pound (#) sign.

Personalize Your Voicemail

- 1. Dial *98 from the phone that's connected to your account.
- 2. Enter your four-digit PIN followed by pound (#) sign.
- 3. Press 8 to access your personal options. They include:

| • | Change PIN | Press 1 |
|---|--------------------------------------|---------|
| • | Personalize your greeting | Press 2 |
| • | Add your personal name | Press 3 |
| • | Call forwarding | Press 5 |
| • | Set call screening forwarding number | Press 6 |
| • | Repeat person options | Press 9 |
| • | Exit the menu | Press 0 |
| | | |

Please call 870-895-3221 for technical support.